



MOBILE 0429 031 488 • PH/FAX 02 4683 0239

**REMOTE BUTTON  
STEERING WHEEL  
MOUNT  
&  
PANEL MOUNT  
SUIT  
MXL**

• **STEP 1**

LOCATE A SUITABLE LOCATION FOR  
MOUNTING QUICK RELEASE PLUG ON  
STEERING WHEEL MOUNTED SW'S  
[NORMALLY IN LOWER DASH PANEL] OR  
SW ASSEMBLIES ON PANEL MOUNT MODELS.

- MOUNT AS REQUIRED



MOBILE 0429 031 488 • PH/FAX 02 4683 0239

## **STEP 2**

ON STEERING WHEEL MODELS RUN CURLY CHORD AROUND COLUMN AND MOUNT DTM DEUTSCH PLUG TO WHEEL WITH CABLE TIES REMOVE SW HARNESS FROM CONNECTOR BY EXTRACTING ORANGE LOCK ASSY AND RELEASE PRIMARY LOCK ASSY AND REMOVE TERMINALS THROUGH THE REAR OF HOUSING NOW EITHER DRILL HOLES THROUGH SPOKES OF WHEEL OR FABRICATE A MOUNT

### **BRACKET**

MOUNT SW AND RE-INSERT TERMINALS INTO HOUSING.

MAKE SURE THAT THE CABLE IS WELL SECURED, THIS WILL STOP THE CABLE FROM BREAKING.

**NOTE:** 4 POLE DTM F/M PINOUT AS FOLLOWS

PIN 1 : COMMON	BLK
PIN 2 : COMMON	BLK
PIN 3 : MEMORY	WHT
PIN 4 : VIEW	BLUE

\*4 POLE DTM MALE ON CURLY CHORD HAS COLOUR CHANGE ,PIN 3 = ORANGE AND



MOBILE 0429 031 488 • PH/FAX 02 4683 0239

### **STEP 3**

RUN PANEL MOUNT END OF HARNESS UP TO  
LOGGER AND TERMINATE TO THE CORRECT  
SOCKETS IN THE 22PIN DEUTSCH PLUG.

CONFIGURE AS FOLLOWS:

PIN 14 = MEMORY      WHITE

PIN 12 = GND            BLK

PIN 15 = VIEW         BLUE

**NOTE:** DUE TO VARIATIONS IN STEERING  
WHEEL DESIGN IT MAY BE NECESSARY TO  
SELF FABRICATE A MOUNT BRACKET FOR  
SW MOUNTING.



PHOTO 1



PHOTO 2



PHOTO 3



PHOTO 4



PHOTO 5