



MOBILE: 0429 031 488 PH/FAX 02 4683 0239  
EMAIL: are01@bigpond.com

## **SCRA AIM LOGGER DASH MOUNT BRACKET INSTALLATION**

- **STEP 1**

ALIGN DASH INSERT INTO ORIGINAL DASH CAVITY, MARK MOUNT HOLES ONTO FACIA(USING INSERT AS THE TEMPLATE).DRILL HOLES AND SECURE INSERT TO FACIA.PREFERABLY USING SUPPLIED M4 ALLEN BOLT AND NUT ASSY.SELFTAPPERS ARE OK BUT ARE PRONE TO VIBRATING LOOSE.REFER PHOTO 1

- **STEP 2**

MOUNT LOGGER TO SEPERATE MOUNT PLATE USING SUPPLIED M4 BOLTS/WASHERS.ATTACH WIRING PLUG TO REAR OF LOGGER.REFER PHOTO 2 & 3

- **STEP 3**

BOLT MOUNTING PLATE TO INSERT.INSTALLATION IS NOW COMPLETE.REFER PHOTO 4.

18/7/05



PHOTO 1 FALCON EA-EB

18/7/05



PHOTO 2 FALCON EA-EB

7/3/05



PHOTO 1 COMMODORE VN-VP

7/3/05



PHOTO 2 COMMODORE VN-VP

7/3/05



PHOTO 3 COMMODORE VN-VP

7/3/05



PHOTO 4 COMMODORE VN-VP